

INSTALLATION INSTRUCTIONS

Part # PG-RSTB-004 - Rear Strut Tower Brace

COMPONENTS:

QTY DESCRIPTION

- 4 M10 NYLON LOCKING NUTS
- 4 SPECIALTY WASHERS
- **1** TEMPLATE "B"
- **1** TEMPLATE "C"
- **1** TEMPLATE "D"
- 1 2" PETTY'S GARAGE DECAL

RECOMMENDED TOOLS:



SCISSORS, BOX CUTTER, CLIP REMOVAL TOOL, WRENCH & TORQUE WRENCH

INSTRUCTIONS:

- Fold both rear seats forward to gain access. Remove trunk floor mat and trunk side panels held in place by plastic push pins. Use a clip removal tool for easier removal of pins.
- **Step 2:** Carefully install rear strut tower brace over the existing strut tower studs.





INSTALLATION INSTRUCTIONS

Step 3: Install 4 cup retainers and nuts on shock studs. Torque rear shock tower nuts to 35 ft/lbs.

Step 4: Using the appropriate Challenger or Charger template, fit the side template on the side panel indentions, cut a hole, and slit out the panel.



Step 5: Reinstall trunk side panels and floor mat.

