



*Performance Vehicles Since 1949*

## Install Instructions Part# PG-SKK-001 Shift Knob Kit

### Required Tools:

- 5/8" Wrench
- 3/4" Wrench

### Installation Instructions:

1. Pull shifter handle boot down below jam nut/threaded bracket. (Top Photo)
2. Use 5/8" wrench to hold OEM shift handle and 3/4" wrench to loosen jam nut.
3. Unscrew and remove OEM shifter handle from threaded bracket.
4. Install PG shift handle and screw down to desired height. Index shift pattern on knob to desired location. Use wrenches to tighten jam nut.
5. Pull shifter handle boot up so that top ring of boot secures in groove of shift handle. (Bottom Photo)

For additional information contact:  
Phone 1-877-498-3745  
Email: [partsinfo@pettys-garage.com](mailto:partsinfo@pettys-garage.com)

