

Part# PG-STB-005
2011- Current 3.6L V-6 Challenger
Strut Tower Brace



Performance Vehicles Since 1949

Required Tools:

- 13mm Socket and ratchet

Installation Instructions:

1. Remove left and right shock mount covers.
2. Using the 13mm socket remove the 6 upper strut mounting nuts.
3. If Brace doesn't align with studs, raise front tires enough to take weight off.
4. Install Brace and reinstall fasteners. Torque 20 ft/lbs.
5. Reinstall factory strut tower covers.



Email: partsinfo@pettys-garage.com