

Tie Down Hooks PG-TDH-001



PG-TDH-001

- Insert Tie Down Hooks into lower sub frame bracket.
- Place lock washers on bolts and start bolts into Tie Down Hooks.
- Torque all hardware to 29 foot-pounds.

